


用前检查

Inspect the container

第①页, PAGE-1



注意事项:

悬挂干燥剂之前, 请先检查集装箱以确保:

1. 集装箱门、壁、地板、顶部均无破损。
2. 集装箱内干净洁净。
3. 检测集装箱木地板水分含量, 不得超过25%, 18%以内为佳。
- ① 木地板含水量超过20%的情况下, 每增加1.5%的湿度, 建议加多1KG干燥剂。
- ② 装运棉麻制品及含水量超过18%的货物, 每增加1.5%的湿度, 建议加多1KG干燥剂。
- ③ 装运草藤编织物及棕榈制品等水分含量较高的货物, 每增加1.5%的湿度, 建议加多2KG干燥剂。

用前检查

Inspect the container

第②页, PAGE-2

NOTICE:

Before using container desiccant, inspect the container, ensuring that:

1. It is free from damage: no holes, gaps in the floor, walls or ceiling, etc.
2. It is clean and dry.
3. Check moisture content of container floor, best keep it below 18%, do not exceed 25%, Had better increase the amount of desiccant in the container.
- ① For floor exceeding 20% moisture content add 1 pc 1kg desiccant for each 1.5%.
- ② For ramie cotton fabric or other products exceeding 18% moisture, add 1 pc 1kg desiccant for each 1.5%.
- ③ For grass rattan fabric, palm products or other high moisture content products, add 2pcs 1kg desiccant for each 1.5%.

悬挂位置

Hanging position

第③页, PAGE-3



20GP



40GP

详细步骤

Using steps (step:1-5)

第④页, PAGE-4



Step 1:

从集装箱内部封住所有透气孔, 如透气孔未被封住, 干燥剂将无法吸尽源源不断进入集装箱的湿气。

Seal air vents, make sure the desiccant in sealed condition.

详细步骤

Using steps (step:1-5)

第⑤页, PAGE-5



Step 2:

打开干燥剂包装纸箱, 取出一袋干燥剂; 拆开干燥剂密封袋, 取出一条干燥剂。

Take the desiccant out of the carton, make sure it is useful.

详细步骤

Using steps (step:1-5)

第⑥页, PAGE-6



Step 3:

Step 3-1:

CODC-91-10的用法
HOW TO USE CODC-91-10?


此款干燥剂较柔软带挂钩, 请借助梯子将干燥剂挂在集装箱两侧的挂环上。

CODC-91-10 is 1kg container desiccant without hard cover that hanging alongside the container wall, please use ladder for help.

详细步骤

Using steps (step:1-5)

第⑦页, PAGE-7



Step 3:

Step 3-2:

CODB-91-10的用法
HOW TO USE CODB-91-10?

此款干燥剂带有硬纸彩卡外壳, 美观坚固带挂钩。可直接将干燥剂悬挂与集装箱内部两侧的挂环上。

CODB-91-10 is 1kg container desiccant with hard colorful cover that hanging alongside the container wall.

详细步骤

Using steps (step:1-5)

第⑧页, PAGE-8



Step 3:

Step 3-3:

CODC-91-14的用法
HOW TO USE CODC-91-14?

此款干燥剂带挂钩与挂绳, 请将挂钩和挂绳分别固定在集装箱两侧的挂环上, 使之悬挂在集装箱顶部, 尽量拉平。

CODC-91-14 is 1.4kg container desiccant with roles that hanging at the roof ceiling of the container.

详细步骤

Using steps (step:1-5)

第⑨页, PAGE-9



Step 3:

Step 3-4:

CODC-91-20C2的用法
HOW TO USE CODC-91-20C2?

此款干燥剂体型小巧, 使用灵活, 主要平放在货物顶部上面。几乎不占用多余的空间; 使用时请注意不要挤压。

CODC-91-20C2 is 2kg container desiccant without hook, flat the desiccant on the surface of the cartons. Do not press!

详细步骤

Using steps (step:1-5)

第⑩页, PAGE-10



Step 4:


干燥剂悬挂完成后, 请尽快将货物装入集装箱内。

Keep loading time short after hanging the desiccant.

详细步骤

Using steps (step:1-5)

第⑪页, PAGE-11



Step 5:

装货完后, 请尽快关闭集装箱门, 避免干燥剂长时间暴露在开放空间中。

Seal the door as soon as possible.

参考用量

Amount (For reference)

第⑫页, PAGE-12



AMOUNT

FOR REFERENCE ONLY

用量对照, 仅供参考

货柜规格 Container	参考用量 Reference amount		
	CODB-91-10	CODC-91-10	CODC-91-14
20GP	6PCS	6PCS	4PCS
40GP	12PCS	12PCS	8PCS
40HQ	14PCS	14PCS	10PCS

CODC-91-10 建议每6立方米空间放置1-2条。

Use 1~2 pcs CODC-91-10 for each 6 CBM.